

ACT-100-U® 10 Year + Additional 20 Year Limited Warranty
Limitations of Liability and Disclaimer

What is Covered by this Warranty

Provided that the conditions set forth below are satisfied, the steel tank manufacturer identified with the tank (hereinafter referred to as "Warrantor") warrants the ACT-100-U® tank for 30 years (10 years + an additional 20 years) following delivery of the tank to the tank owner at the time of the original installation ("the Owner"), against any of the following events which may occur, provided the event occurs under operating conditions covered by this Warranty: (i) non-corrosion related structural failure; (ii) corrtank with its soil environment; and (iii) perforation of the tank caused by internal corrosion for those tanks equipped with wear plate(s) and used to store heating or motor fuels, including alcohols and other compatible contents, which is caused by these heating or motor fuels, alcohols and other compatible contents. In addition, the Warrantor warrants the tank against failure due to defective materials and workmanship for up to 1 year following the delivery of the tank to the Owner.

Conditions to Warranty Effectiveness

The limited warranties set forth herein are subject to the following conditions:

1. The ACT-100-U® tank: (i) must be the original underground installation within the Continental United States of America, Alaska, Hawaii, and the Commonwealth of Puerto Rico or Canada; (ii) installed, operated and maintained in accordance with the applicable ACT-100-U® specifications and the applicable ACT-100-U® Installation Instructions that were in effect on the date of shipment by the Warrantor, any subsequent maintenance procedures of which the Owner has written notice, and any applicable governmental codes and regulations; and (iii) operated at a temperature no greater than the maximum temperature limitations of the tank and its components as set forth in the specifications for the tank, which state that stored product shall not be heated; and (iv) not used for the storage of #6 heated oil. Refer to the Installation Instructions on the back of this document for technical requirements concerning relocation of this tank by the original owner, in order to retain warranty eligibility. Tanks remaining in their original installation location will retain warranty eligibility if the facility where the tank is installed is sold to a new owner.
2. This Limited Warranty is not valid unless, and until, the Warranty Validation Card is fully completed by the Owner and returned to Steel Tank Institute (STI) within 30 days after the date of tank installation, or 90 days after the Warrantor's shipment of the tank, whichever comes first.
3. Upon discovery of a suspected tank failure or leak by the Owner, the Owner shall give the Warrantor written notice of the suspected tank failure or leak and permit the Warrantor or its designated representative to inspect the tank site prior to, during and after excavation of the tank. The tank owner bears the responsibility to identify that the cause of the failure is from one of the events within the Conditions covered by the Warranty.
4. Upon the Warrantor's determination that the tank failure or leak is covered by this Limited Warranty, the Warrantor at its sole option shall: (1) repair the tank; or (2) replace it with a tank of approximately the same size, design, quality of material and workmanship specified for the original tank; or (3) refund the purchase price of the original tank. If the Warrantor is unable to repair or replace the tank, it shall refund the original purchase price of the tank.

What is Not Covered by this Warranty

Warrantor does not warrant any piping system or any other attachments connected with the tank. Under no circumstances, shall the Warrantor be liable for (1) the cost of repair or replacement of any piping system or other attachments to the tank; or (2) labor costs or other installation costs for tank repair or replacement; or (3) damage to the tank or other property resulting from the accumulation of water in the tank; or (4) damage caused by other improper operating or maintenance practices; or (5) failures resulting from gage stick damage occurring under tank openings other than the designated opening with a wear plate installed; or (6) tank failure due to defective materials and workmanship later than one year following delivery of the tank to the Owner or (7) cost of repair or replacement of internal linings.

Limitation of Liability and Exclusion of Other Remedies and Damages

The foregoing remedy of repair, replacement or refund shall constitute the sole and exclusive remedy to the Owner. Under no circumstances, shall the liability of the Warrantor, or its affiliates or subsidiaries, under this warranty, exceed the purchase price of the tank.

IN NO EVENT SHALL THE WARRANTOR, OR ITS AFFILIATES OR SUBSIDIARIES, BE LIABLE FOR CLAIMS OF PERSONAL INJURY OR FOR SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE, LOSS OF USE OF THE TANK OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF THE SUBSTITUTE EQUIPMENT, FACILITIES OR SERVICES, DOWNTIME COST, CLAIMS OF CUSTOMERS OF THE OWNER FOR SUCH DAMAGES, OR FOR DAMAGE TO PROPERTY, WHETHER SUCH CLAIM SHALL BE FOR BREACH OF CONTRACT, BREACH OF WARRANTY, NEGLIGENCE OR STRICT LIABILITY, AND WHETHER SUCH CLAIM ARISES OUT OF OR RESULTS FROM THIS LIMITED WARRANTY, OR EXPRESS OR IMPLIED WARRANTIES, OR FROM THE DESIGN, MANUFACTURE, SALE, DELIVERY, RESALE, INSTALLATION, TECHNICAL DIRECTION OF INSTALLATION, INSPECTION, REPAIR, OPERATION OR USE OF THE TANK.

Consumer Notice

The exclusion of indirect or consequential damages and the limitation of implied warranties herein may not be applicable to purchasers who are deemed "consumers" and who reside in states that do not allow the limitation of implied warranties or the exclusion of indirect or consequential damages otherwise applicable to consumers. Moreover, if you are deemed a "consumer", you may have specific legal rights in addition to those set forth in this warranty, which rights vary from state to state.

Disclaimer of Other Warranties

THE FOREGOING LIMITED WARRANTY IS THE ONLY WARRANTY MADE. THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Financial Assurance

Warrantor may have purchased insurance to cover some of its warranty obligations under this Limited Warranty. Such insurance would provide financial assurance for Warrantor's warranty obligations, but would not insure the Owner directly. If the Warrantor has purchased such insurance coverage, the Owner may request that the Warrantor provide a certificate of insurance to evidence Warrantor's purchase of such insurance.

Effective with installations on or after January 1, 2011

ACT-100-U® INSTALLATION INSTRUCTIONS

1.0 EXCAVATION AND BEDDING

- 1.1 The bottom of the excavation shall be covered with a minimum of 12 inches (305 mm) of bedding, suitably graded and leveled. Bedding and backfill material surrounding the tank, to a width and depth of 12 inches (305 mm) all around the tank, shall be clean material.
- 1.2 Where anchoring by means of a concrete pad, the tank shall not be placed directly on the pad. Bedding material at least 6 inches (152.4 mm) deep must be spread evenly over the dimensions of the pad to separate the tank from the pad.
- 1.3 Bedding and backfill material shall consist of homogenous pea gravel, crushed stone, clean sand, natural earthen materials, or excavatable flowable fill. Crushed stone, clean sand and natural earthen materials shall be capable of passing 100% through a 1/2 inch (13 mm) sieve and no more than 12% by dry weight through a #200 sieve (0.0029 inch (0.0754 mm)). Pea gravel shall be no larger than 3/4-inch (19 mm). Flowable fill shall meet the National Ready Mixed Concrete Association for Controlled Low Strength materials (CLSM) with strengths ranging from 70 – 150 psi and shall be installed in accordance with good engineering practice. The materials shall be free of all foreign materials, such as but not limited to, bricks, metals, concrete and plastics.
- 1.4 The backfill material may be from the tank site if it meets this description, or it may be delivered to the site from another source.
- 1.5 Sand or natural earthen materials used as backfill shall be placed into the excavation in 12-18 inch (305-458 mm) vertical lifts, compacted after each lift, at least 60% up the vertical height of the tank.
- 1.6 If earthen material from the site, or other earthen material, is to be used as bedding or backfill material, a minimum of four 1 cu. ft. samples shall be taken from different locations which are representative of the backfill material and the site. Samples shall be sieved to determine if the material complies with this specification.
- 1.7 In a tidal area, the tank "bedding" material shall be crushed stone or pea gravel. Sand and natural earthen material may be used only if measures are taken to prevent washout of material during the design life of the system.

2.0 AIR TEST AT JOB SITE

- 2.1 The temporary plugs and thread protectors installed by the manufacturer shall be removed. Apply compatible, non-hardening pipe sealant to internal bushing threads. Permanent metal plugs shall be installed at all unused openings.
- 2.2 If the manufacturer has shipped a double wall tank with a vacuum on the interstitial space, read and record the vacuum pressure. If the vacuum gauge reading has dropped more than 2 inches Hg (6.77 kPa), from the level at which it was shipped, contact the tank manufacturer.
- 2.3 To conduct a soap solution/air pressure test, follow these steps:
 1. The nylon bushings in the tanks shall not be removed from the unused openings. Plugs used to temporarily seal the tank for the above ground air test, but later removed for pipe installation, shall not be over tightened. Do not cross thread or damage the nylon bushings when replacing plugs or installing required tank piping.
 2. Test pressure shall be maintained at, without exceeding, 5 psig (34.47 kPa) while a soap solution is applied to the area of pipe connections and welds.
 3. Dual wall tanks shall require different air pressure testing procedures. Do not connect a high pressure air line directly to the interstitial monitoring port. A factory applied vacuum within the interstitial space can be used in lieu of, or in addition to, the air test procedure. Consult tank fabricator for air test recommendations. Do not apply a vacuum to the primary tank or a single wall tank. PEI/RP 100-00 also provides guidelines.
 4. Take necessary safety precautions during air tests. Do not leave tanks unattended. Avoid standing at the head of the tank, especially while applying air pressure. Use an air-pressure relief valve.
- 2.4 In lieu of the air pressure test described above in paragraph 2.3, a vacuum may be applied to the interstice of a double-wall tank. DO NOT APPLY A VACUUM TO THE PRIMARY TANK OF A DOUBLE-WALL TANK OR TO A SINGLE-WALL TANK. A vacuum of 6 inches Hg (20.3 kPa) is to be applied to the interstice. The vacuum shall be held without a loss for one hour on tanks less than 20,000 gallons and for 2 hours for tanks greater than or equal to 20,000 gallons. If this vacuum cannot be held for the specified time interval, then perform the air test procedure described in section 2.3.

3.0 TANK INSPECTION

- 3.1 This tank is shipped with protective material attached. This material must remain on the tank and shall not be removed. Before placing the tank in the excavation, all dirt clods and similar foreign matter shall be cleaned from the surface of the tank. Set the tank on the ground such that the protective material is between the tank and the ground.
- 3.2 Visually inspect the tank for damage. Pay particular attention to areas where cladding has been gouged or abraded. Mark all areas which appear damaged for repair. Any section of the cladding, which has been damaged beyond the surface of the cladding, shall either be repaired or spark tested. Spark testing shall be done with a holiday detector set at a minimum 10,000 volts.
- 3.3 Coat all holidays, damaged cladding, and/or exposed steel surfaces using touch-up kit furnished by tank supplier. Follow manufacturer's instructions for mixing and application of resin. (See Section 9 for touch-up procedures.) All holidays shall be re-tested at 10,000 volts.

4.0 TANK HANDLING & PREPARATION

- 4.1 Controlled off-loading of the tank shall be allowed.
- 4.2 Equipment to lift the tank shall be of adequate size to lift and lower the tank without dragging or dropping to prevent damage to the tank or the coating.
- 4.3 Tank shall be carefully lifted and lowered off of the truck and into the excavation hole by use of cables or chains of adequate length attached to the lifting lugs provided. A spreader bar should be used where necessary. Under no circumstances shall chains or wire rope slings be used around the tank shell.
- 4.4 Follow label instructions including those at tank openings.
- 4.5 This tank requires venting. Refer to applicable local codes and PEI RP-100 for proper installation.

5.0 ANCHORING

- 5.1 High water tables or partially flooded excavation sites exert significant buoyant forces on tanks. Buoyant forces are partially resisted by the weight of the tank, the backfill and the pavement atop the tank. Additional buoyant restraint when required, shall be obtained by using properly designed hold-down straps in conjunction with concrete hold-down pads or deadman anchors. The use of steel cable or round bar as hold-down straps is prohibited.
- 5.2 If a metallic hold-down strap is used, a pad of inert insulating di-electric material must be used to insulate the hold-down strap from the tank. The separating pad shall be wider than the hold-down straps, which will prevent direct contact between the straps and the tank shell. This pad is not required if the hold-down strap is fabricated from non-conductive material.
- 5.3 Ballasting the tank may be necessary. When water is used as the ballast material, it shall only be potable water and shall not remain in the tank longer than 60 days. During construction, adequately vent all tank spaces. If product is used as ballast, proper precautions must be taken to prevent fires, spills, leaks, and other associated accidents. Monitor product level frequently to ensure there has been no unaccounted loss of product. Do not over tighten hold-down straps beyond snug and do not re-tighten hold-down straps after ballasting.

6.0 BACKFILL

- 6.1 Homogeneous backfill material similar to the bedding material shall be carefully placed around the entire tank to create a uniform homogeneous environment. Avoid damage to cladding especially where tamping is required.
- 6.2 Installing and tamping backfill along the bottom sides of the tank shall ensure that the tank is fully and evenly supported around the bottom quadrant.

7.0 ELECTRICAL ISOLATION

- 7.1 All openings shall be isolated where electrical accessories will be installed such as submersible pump, monitoring equipment and all other grounded electrical devices.
- 7.1.1 Prior to backfilling over top of tank, all openings shall be visually inspected to assure that the di-electric isolation (nylon bushings or flange gaskets), where furnished, remain in place. Where flanged openings have been used, isolation of the flange gaskets shall be confirmed with a continuity tester. Contact with the tank shall be made with the inside of the tank, or possibly at the lift lug, if steel is exposed, prior to application of the lift lug cover. No current shall pass through the factory installed flanged gaskets. Isolation of the fittings is required to assure tank integrity.
- 7.2 If the tank is to be installed in the presence of an impressed current system, the effect of the system must be considered on the ACT-100-U®. The corrosion consultant must consider including the ACT-100-U® tank into the design of the impressed current system.

8.0 FINAL AIR TEST

- 8.1 Install required tank piping using compatible non-hardening sealant, taking care not to cross thread or damage the nylon. Torque of 400 to 1,000 ft-lbs (542.3 to 1355.8 N-m) may be required to fully insert pipe.
- 8.2 Where air or hydrostatic testing is required after installation, the pressure applied shall not be in excess of 5 psig (34.5 kPa) as measured at the top of the tank. A soap solution shall be applied around pipe connections while air test is being performed.

9.0 SEALING OF PIPE CONNECTIONS, LIFTING LUGS AND REPAIRS

- 9.1 The fabricator, per STI specifications, has applied the cladding over all steel surfaces. During the installation process, steel can become exposed at the lift lug due to handling of the tank. Steel may also be expressed at the interface between the steel tank and the electrical isolation fitting. These areas, along with all other exposed steel surfaces, must be covered via the touch-up kit supplied by the manufacturer. After application, the installer shall verify that the required area has cured (adequate material hardness and solidification) prior to backfill. Normal cure time may vary.
- 9.2 Clean areas to be repaired through removal of surface rust, dirt, contaminants, and disbonded cladding. The cladding surrounding all holidays, cladding flaw areas, and/or exposed steel areas should be surface prepared by using a coarse grit, sandpaper or grinder. (Refer to SSPC SP-2 "Hand Tool Cleaning" or SP-3 "Power Tool Cleaning" for additional guidance). This process should remove all glossiness from the surface surrounding the repair area within 6 inches (152 mm) of the holiday.
- 9.3 After an air test has established tightness, tank fittings shall receive a coat of urethane or be covered with a coat of the repair material prior to backfill. (Refer to section 9.2 for surface preparation). Area to be coated shall include the entire plug on unused fittings.

10.0 FINAL BACKFILL

- 10.1 Homogeneous backfill shall be deposited carefully around the tank and to a depth of at least one foot (305 mm) over the tank. (See NFPA 30 and state or local codes for minimum depth of cover required).
- 10.2 If cladding damage occurs after holiday testing or during backfill operation, repairs shall be made in accordance with Section 9.

11.0 OPERATING LIMITATIONS

- 11.1 Tanks shall be operated at ambient temperatures only. The tank manufacturer must be notified, prior to tank use, of the owner's intent to operate this tank above ambient temperature so that the proper components and materials can be incorporated.

12.0 MAINTENANCE

- 12.1 The primary tank shall be inspected monthly for the presence of water. Inspection shall take place at the lowest possible points inside the primary tank. Remove any water found. Water and sediment in fuel can cause plugging of filters. Also, bacterial growth, originating from the fuel, can cause filters to plug and corrosion of tanks and lines. For procedures on how to check for the presence of water and removal of water, refer to the STI R111, Storage Tank Maintenance. For copies of the RP and more information, please go to www.steelintank.com.
- 12.2 Tank must be installed within one year of delivery from tank manufacturer. If tank is not installed within this time period, contact tank manufacturer to recertify the tank.
- 12.3 Safety considerations and controls should be established prior to undertaking physical activities associated with USTs. Some hazards associated with USTs are, but not limited to, confined space entry, cleaning, inspection, moving and any other aspect of in-service work.
- 12.3.1 Contact tank manufacturer before moving tank for information on recertifying tank for continued use.

5/2015

These instructions are intended only as an aid to tank installers who are knowledgeable and experienced in underground tank installation. Compliance herewith does not necessarily meet the requirements of applicable federal, state and local laws, regulations and ordinances concerning tank installation. STI makes no warranties, express or implied, including but not limited to, any implied warranties of merchantability or fitness for a particular purpose, as a result of these installation instructions.